


3104 106 50900  
or 3104 106 51070



Conn. voltage adapter

110V	7-4	1-2	3-4
220V	7-4	2-3	
127V	7-6	1-2	3-4
240V	6-5	2-3	

3104 106 01570

3104 106 01572

Rec-repr	Switch		
Recording	Reprod		
1-3	3-5		
2-4	4-6		
7-9	15-16		
TRACK SELECTOR			
8-10	25-29	1-4	2-3 Parallel
13-14	28-34	201-203	201-205 203-212
20-22-24	31-33	204-206-208	202-206-208
21-23	21-22	207-209	207-209
27-28-25	217-219	213-219	213-217-219
33-34	214-220	218-220	214-218-220
LINE SWITCH			
		301-303	303-305
		302-204	304-306
SPEED SELECTOR EXTRA LS			
		307-309	309-311 4.76 95
		308-310	310-312 401-402 403-404 501-502