


# REMOTE-CUTOFF BEAM PENTODE

High-Voltage, Low-Current, Regulator Type TENTATIVE DATA

RCA-5890 is a low-current beam pentode of the remote-cutoff type intended particularly for the voltage regulation of high-voltage dc power

supplies. It has a maximum do plate-voltage rating of 30000 voits, a maximum do plate-current rating of 500 microamperes, and a maximum plate-dissipation rating of 10 watts.



# **GENERAL DATA**

#### Electrical:

5890

			Unipotential	Cathode:
U CLUI	Vol	tage (A	c or DC).	6.3 volts
	Cur	rent .		0.6 ampere
	Mu-Fa	ictor, G	rid №0.2	•
			d No.1	5
Direct Interelect	rode	Capacit	ances:	•
Grid No. 1 to Pl				018 بي <b>ر</b>
Input				7.5 µµ1
Input Output				1.6 juit
,				
Mechanical:				
Mounting Resition				454
Mounting Position Overall Length . Seated Length .				A A COR A A CUR
Easted Length .				6-1/2" ± 1/4"
Seated Length				0" ± 1/4"
Maximum Diameter				
Cap				
Base			. Small-Shell	puodecal 7-Pin
Bulb Temperature	(At h	ottest	point)	220 max. OC

#### **VOLTAGE-CONTROL SERVICE**

Maximum	ccs	Ra	ting	ıs,	4	bsc	olu	ta	7	alı	ue:	9:			
DC PLAT	E VOL	TAG	Ε.										30000	max.	volts
DC GRID	-NO.3	3 VO	LTAG	ìΕ	٠								6600	max.	volts
DC GRID	-No.2	2 VO	LTAG	Έ					٠				450	max.	volts
DC GRID															
Negat	ive t	pias	val	ue						٠	٠	•	200	max.	volts
Pošit	ive t	ias	val	ue					٠			٠	0	max.	volts
Posit													2	max.	volts
MAXSI	GHAL.	DC	PLAT	Έ (	CUI	RRI	ENT						500	max.	⊬amp
MAX\$1	GNAL	GRI	D-# 0	. 3	- 11	I PI	JT.		٠				1	max.	watt
MAX\$1	GNAL	GRI	D-N 0	. 2	-10	N PL	JT.						0.1	max.	watt

Continuous Commercial Service.

PEAK HEATER-CATHODE VOLTAGE: Heater negative with respect to cathode: During equipment warm-up period not exceeding 15 seconds. . After equipment warm-up period . . Heater positive with 450 max. volts 165 max. volts

respect to cathode.

165 max.


volts

### Typical Operation As Shunt Voltage-Regulator Tube

	in Accompanying Circuit:
DC Plate voltage	20000 30000 volts
DC Grid-No.3 Voltage	5500 5500 volts
DC Grid-No.2 Voltage*	200 200 volts
DC Grid-No.2 Voltage* DC Grid-No.1 Voltage**	
oc aria-no.1 voitage	
Peak Grid-No.1 Voltage	45 20 volts
Zero-Signal DC Plate Current .	0 0 μáπp
MaxSignal DC Plate Current .	500 60 #amp
Zero-Signal DC Grid-No.3	•
Current	0 0 #amp
MaxSignal DC Grid-No.3	
Current	0 0 <i>µ</i> -amp
Zero-Signal DC Grid-No.2	,
Current	0 0 μamp
MaxSignal DC Grid-No. 2	• • • • • •
Current	0 0 <u>#amp</u>
Grid-No.1 Bias (Approx.) for	, , , , , , , , , , , , , , , , , , ,
	-52 -52 volts
plate current of 10 mamp.	-52 -52 volts
Grid-No.1-Plate	
Transconductance	11 2 umbos

- Subject to variation of ± 40% if grid-No.1 voltage is desired at indicated value.
- Subject to variation of ± 40% if grid-No.2 voltage is desired at indicated value.

# SHUNT VOLTAGE-REGULATOR CIRCUIT



NOTE: THE CONTROL VOLTAGE MAY BE TAKEN FROM THE LOAD CIRCUIT OR FROM A CIRCUIT SUPPLYING SIGNAL TO THE LOAD CIRCUIT, DEPENDING ON THE TYPE OF LOAD INVOLVED.

# OPERATING NOTES

The maximum ratings in the tabulated data for the 5890 are limiting values above which the serviceability of the 5890 may be impaired from the viewpoint of life and satisfactory performance. Therefore, in order not to exceed these absolute ratings, the equipment designer has the responsibility of determining an average design


PLATE DISSIPATION. .

watts

10 max.

value for each rating below the absolute value of that rating by an amount such that the absolute values will never be exceeded under any usual condition of supply-voltage variation, load variation, or manufacturing variation in the equipment itself.





The high dc voltages at which the 5890 is operated may be extremely dangerous to the user. Great care should be taken during the adjustment

of circuits. The tube and its associated apparatus, especially all parts which may be at high potential above ground, should be housed in a protective enclosure. The protective housing should be designed with interlocks so that personnel cannot possibly come in contact with any high-potential point in the electrical system. The interlock devices should function to break the primary circuit of the high-voltage supply when any gate or door on the protective housing is opened, and should prevent the closing of this primary circuit until the door is again locked.

It should always be remembered that high voltages may appear at normally low-potential points in the circuit because of capacitor breakdown or to incorrect circuit connections. Therefore, before any part of the circuit is touched, the power-supply switch should be turned off and both terminals of any capacitors should be grounded.

The temperature of the bulb may be measured either with a thermocouple or with temperature-sensitive paint, such as Tempilaq. The latter is made by the Tempil Corporation, 132 West 22nd Street, New York 11, N.Y., in the form of liquid and stick, and is stated by the manufacturer to have an accuracy of 1 per cent.

Operation of the 5890 with a plate voltage above approximately 16000 volts results in the production of soft x-rays which can constitute a health hazard on prolonged exposure unless the tube is adequately shielded. Relatively simple shielding should prove adequate, but the need for this precaution should be considered in equipment design (see References 1 and 2).

Under normal operating conditions, the 5890 may exhibit a blue glow on the upper half of the inner surface of the bulb wall and a red or orange glow on the plate. These effects are caused by fluorescence and are not to be mistaken for gas and overheating of the plate.


# REFERENCES

- . "Nedical I-ray Protection Up To Two Million Folts,"
  National Bureau of Standards Handbook H41.
- . "Safety Code for Industrial Use of I-rays," American Standards Association, ASA Code 25%-1-1946.


Devices and arrangements shown or described herein may use patents of RCA or others. Information contained herein is furnished without responsibility by RCA for its use and without prejudice to RCA's patent rights.



# DIMENSIONAL OUTLINE



# SOCKET CONNECTIONS Bottom View



PIN 1: HEATER

PIN 2: GRID NO.1

PIN 6: GRID NO.3

PIN 7: INTERNAL CONNECTION—DO NOT USE

PIN 10: GRID NO. 2 PIN 11: CATHODE PIN 12: HEATER CAP: PLATE

